



INSTALLATION INSTRUCTIONS

PART No.

50730

**Jeep® JK Wrangler
Hood Lift Supports**



REQUIRED TOOLS

Philips Screw Driver
Drill
5/16" Drill Bit
3/32" Drill Bit
13mm Socket
12mm Wrench
Body Clip Remover
Marker

KIT CONTAINS

Hood Struts (Left & Right)
Bracket Mount
Ball-fitted Stud
Serrated Nut
Self-tapping Screw

QTY

1ea
2
4
4
4

5073000



INSTALLATION INSTRUCTIONS


PART No.

50730

**Jeep® JK Wrangler
Hood Lift Supports**

1) PREPARE

Under the hood, remove the shown body clip from both driver and passenger sides.



With a 5/16" drill bit, drill out this hole on each side.

2) MEASURE

From the inner most edge of the hood on each side, measure up along the flat face 21" and mark a line. The bracket should not go past this mark.



Place the very edge of the mounting bracket on this line, and mark the location of the three holes.





INSTALLATION INSTRUCTIONS

PART No.

50730

**Jeep® JK Wrangler
Hood Lift Supports**

With a 3/32" drill bit, carefully drill these locations out.

3) **ASSEMBLE**

Begin screwing in the mounting brackets so that each flange points inward.

Screw into the single bracket hole one ball-fitted stud with a serrated nut, using a 13mm socket and 12mm wrench, so that the stud points outwards.

Screw another ball-fitted stud into the bottom hole that was previously drilled out, so that the stud points inwards.



With the support oriented with the oil casing pointing down, snap each joint onto the ball studs, and repeat on the opposite side.