



INSTALLATION INSTRUCTIONS

PART No. 30508 & 20504

MODEL No.



Rear Cross Member



Place rear bumper brackets as shown on the rear cross member and fasten using 3/8" stainless bolts. Place the bumper on the bumper brackets and fasten bumper to brackets.



INSTALLATION INSTRUCTIONS

PART No. 30508 & 20504

MODEL No.



Rear Cross Member



Place rear bumper brackets as shown on the rear cross member and fasten using 3/8" stainless bolts. Place the bumper on the bumper brackets and fasten bumper to brackets.