


INSTALLATION INSTRUCTIONS PART NUMBER 30577 & 30587



Remove the two inside screws holding the tail light to the body. Remove the tail light housing. Remove the gas cap and the plastic strap from the filler neck. **CAUTION Gas fumes can be dangerous NO OPEN FLAME.** The factory filler neck is plastic and it is held in place by two tabs. To release the filler neck push on the inside two tabs while pushing or pulling on the filler neck. The rubber gromet will cause resistance this gromet can be removed to make this process easier. Clean the outer surface of the body using isopropyl alcohol. Position the new Stainless Steel filler neck, insert the gas filler neck tube into the rubber gromet provided with the SS gas filler neck. Remove the 3M tape backing and secure the filler neck to the body. Screw the gas cap into the gas filler neck and insert the strap into the hole in the filler neck. Reconnect the tail light and secure with the two screws removed earlier.

INSTALLATION INSTRUCTIONS PART NUMBER 30577 & 30587



Remove the two inside screws holding the tail light to the body. Remove the tail light housing. Remove the gas cap and the plastic strap from the filler neck. **CAUTION Gas fumes can be dangerous NO OPEN FLAME.** The factory filler neck is plastic and it is held in place by two tabs. To release the filler neck push on the inside two tabs while pushing or pulling on the filler neck. The rubber gromet will cause resistance this gromet can be removed to make this process easier. Clean the outer surface of the body using isopropyl alcohol. Position the new Stainless Steel filler neck, insert the gas filler neck tube into the rubber gromet provided with the SS gas filler neck. Remove the 3M tape backing and secure the filler neck to the body. Screw the gas cap into the gas filler neck and insert the strap into the hole in the filler neck. Reconnect the tail light and secure with the two screws removed earlier.